All manuals and user guides at all-guides.com

aiwa

aiwa SERVICE

NSX-A222
NSX-A223
NSX-S222
NSX-S333

COMPACT DISC /
STEREO CASSETTE RECEIVER

• TYPE: U<A222/A223>
LH<S222/S333>

SERVICE MANUAL

SIMPLE MANUAL

• Replace this Service Manual with "Revision Publishing" when it is issued.

S/M Code No. 09–98C–312–6T1

all-guides.com

All manuals and user guides at all-guides.com

ELECTRICAL MAIN PARTS LIST - 1/8

NOTE: The characters in the suffix column indicate the part usage.

LH(Lo) .....XX.....A.....
U .....XX.....B.....
LH(Hi) .....XX.....C.....

REF.NO	PARTS NO.	KANRI NO.	DESCRIPTION	SUFFIX
	82-NF7-210-110		GUIDE,FL (*)	ABC
*	8Z-NF9-201-010		GUIDE,OPE 1W	ABC
*	8Z-NF9-202-010		GUIDE,OPE R	...
C 101	87-A11-140-080		CAP,TC U 0.047-50 K B	ABC
C 153	87-010-221-080		CAP, ELECT 470-10V	ABC
C 151	87-A11-142-080		CAP,TC U 0.068-50 K B	ABC
C 204	87-010-246-040		CAP,E 47-35 SME	ABC
C 201	87-010-421-040		CAP,E 4.7-50 5L	ABC
C 202	87-010-421-040		CAP,E 4.7-50 5L	ABC
C 203	87-010-560-040		CAP,E 10-50 GAS	ABC
C 205	87-018-205-080		CAP, CERA-SOL 0.022	ABC
C 210	87-010-060-040		CAP,E 100-16	ABC
C 213	87-015-695-040		E/CAP 1UF 50V TAPG	ABC
C 218	87-018-125-080		CAP, CER 330P-50V	ABC
C 217	87-018-125-080		CAP, CER 330P-50V	ABC
C 219	87-018-131-080		CAP, CER 1000P-50V	ABC
C 216	87-018-131-080		CAP, CER 1000P-50V	ABC
C 212	87-018-205-080		CAP, CERA-SOL 0.022	ABC
C 211	87-A10-189-040		CAP,E 220-10	ABC
C 214	87-A11-155-080		CAP,TC U 0.01-16 Z F	ABC
C 221	87-018-104-080		CAP,TC-U 10P-50 SL	ABC
C 222	87-018-128-080		CAP, CERA-SOL SS 560P	ABC
C 220	87-018-205-080		CAP, CERA-SOL 0.022	ABC
C 224	87-018-205-080		CAP, CERA-SOL 0.022	ABC
C 231	87-015-681-040		E/CAP 10-16	ABC
C 230	87-A11-140-080		CAP,TC U 0.047-50 K B	ABC
C 232	87-A11-140-080		CAP,TC U 0.047-50 K B	ABC
C 234	87-A11-140-080		CAP,TC U 0.047-50 K B	ABC
C 244	87-018-117-080		CAP,TC-U 68P-50 SL	ABC
C 241	87-018-117-080		CAP,TC-U 68P-50 SL	ABC
C 243	87-018-117-080		CAP,TC-U 68P-50 SL	ABC
C 242	87-018-117-080		CAP,TC-U 68P-50 SL	ABC
C 245	87-018-117-080		CAP,TC-U 68P-50 SL	ABC
C 246	87-018-118-080		CAP,TC-U 82P-50 B	ABC
C 252	87-018-131-080		CAP, CER 1000P-50V	ABC
C 701	87-018-115-080		CAP, CER 47P-50V	ABC
CN 701	87-099-013-010		CONN,11P 6216 V	ABC
CON 102	87-099-015-010		CONN,13P 6216V	ABC
CON 101	87-099-720-010		CONN,30P TYK-B(P)	ABC
D 151	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 202	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 203	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 201	87-A40-509-080		ZENER,MTZJ6.8C	ABC
D 214	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 217	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 213	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 218	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 215	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 212	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 216	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 219	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 228	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 220	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 229	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 222	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 227	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 221	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 225	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 224	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 226	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 223	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 230	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 237	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 234	87-020-465-080		DIODE,1SS133 (110MA)	...
D 232	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 238	87-020-465-080		DIODE,1SS133 (110MA)	...
D 240	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 701	87-020-465-080		DIODE,1SS133 (110MA)	ABC
D 702	87-020-465-080		DIODE,1SS133 (110MA)	ABC
FL 301	8Z-NF9-610-010		FL,SVA-10MS12	ABC
IC 202	87-A20-914-010		IC,SPS-442-1-F	ABC
IC 201	8Z-NF9-630-010		C-IC,M38B59MFH-P101FP	ABC
L 201	87-A50-434-010		COIL,CLK 4.19M(TOKO)	ABC
LED 604	87-A40-619-080		LED,SLR-56PT-TE7-W GRN	ABC
LED 609	87-A40-619-080		LED,SLR-56PT-TE7-W GRN	...
LED 602	87-A40-619-080		LED,SLR-56PT-TE7-W GRN	ABC
LED 608	87-A40-619-080		LED,SLR-56PT-TE7-W GRN	...
LED 605	87-A40-619-080		LED,SLR-56PT-TE7-W GRN	ABC
LED 601	87-A40-619-080		LED,SLR-56PT-TE7-W GRN	ABC
LED 603	87-A40-619-080		LED,SLR-56PT-TE7-W GRN	ABC
Q 101	87-026-218-080		TR,DTC144ES (0.2W)	ABC
Q 102	87-026-218-080		TR,DTC144ES (0.2W)	ABC
Q 152	87-026-609-080		TR,KTA1266GR	ABC
Q 153	87-026-610-080		TR,KTC3198GR	ABC

All manuals and user guides at all-guides.com

ELECTRICAL MAIN PARTS LIST - 2/8

Q	151	87-026-610-080	TR,KTC3198GR	ABC.....
Q	206	87-026-215-080	TR,DTC114YS	ABC.....
Q	205	87-026-610-080	TR,KTC3198GR	ABC.....
Q	203	87-026-610-080	TR,KTC3198GR	ABC.....
Q	204	87-A30-090-080	FET,2SK2541	ABC.....
Q	202	87-A30-090-080	FET,2SK2541	ABC.....
Q	201	87-A30-090-080	FET,2SK2541	ABC.....
Q	602	87-026-287-080	TR,DTC143ES	ABC.....
Q	606	87-026-287-080	TR,DTC143ES	ABC.....
Q	601	87-026-287-080	TR,DTC143ES	ABC.....
Q	604	87-026-287-080	TR,DTC143ES	.....
Q	605	87-026-287-080	TR,DTC143ES	ABC.....
Q	603	87-026-287-080	TR,DTC143ES	ABC.....
Q	701	87-026-245-080	TR,DTC114ES	ABC.....
Q	702	87-A30-240-080	TR,CSA1585BC	ABC.....
Q	703	87-A30-241-080	TR,KTA1272Y	ABC.....
Q	704	87-A30-241-080	TR,KTA1272Y	ABC.....
S	201	87-A90-535-010	SW,RTRY EC16B24304	ABC.....
S	202	87-A90-791-010	SW,RTRY EC16B12204 ENCODER	ABC.....
S	304	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	306	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	307	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	303	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	308	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	305	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	301	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	302	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	309	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	310	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	317	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	318	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	314	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	312	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	316	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	319	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	321	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	325	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	320	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	329	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	323	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	322	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	324	87-A90-095-080	SW,TACT EVQ11G04M	ABC.....
S	330	87-A90-095-080	SW,TACT EVQ11G04M	.....
C	402	87-010-112-040	CAP,E 100-16	.....
C	409	87-010-265-040	CAP,E 33-16 SME	.....
C	405	87-010-544-040	CAP,E 0.1-50 SME	.....
C	407	87-015-699-040	CAP,E 10-50 7L	.....
C	404	87-018-117-080	CAP,TC-U 68P-50 SL	.....
C	408	87-018-118-080	CAP,TC-U 82P-50 B	.....
C	406	87-A11-144-080	CAP,TC U 0.1-50 K B	.....
C	403	87-A11-149-080	CAP,TC U 0.22-50 Z F	.....
C	401	87-A11-154-080	CAP,TC U 4700P-16 Z F	.....
C	410	87-A11-140-080	CAP,TC U 0.047-50 K B	.....
EMI	401	87-008-372-080	FILTER, EMI BL OIRNI	.....
J	401	87-A60-651-010	JACK,3.5MONO	.....
Q	404	87-026-609-080	TR,KTA1266GR	.....
Q	402	87-026-609-080	TR,KTA1266GR	.....
Q	403	87-026-610-080	TR,KTC3198GR	.....
Q	401	87-026-610-080	TR,KTC3198GR	.....
Q	406	87-026-610-080	TR,KTC3198GR	.....
Q	405	87-A30-090-080	FET,2SK2541	.....
VR	401	86-NFA-607-010	VR,RTRY 10K15AX1 1 V XV0121PVN	.....
FC	1	87-033-213-080	CLAMP, FUSE	.B.....
FC	2	87-033-213-080	CLAMP, FUSE	.B.....
PR	102	87-026-681-080	PROTECTOR,5A 60V 491	A.....
PR	101	87-026-681-080	PROTECTOR,5A 60V 491	A.....
T	1	87-A60-317-010	TERMINAL, 1P MSC	.B.....
T	2	87-A60-317-010	TERMINAL, 1P MSC	.B.....
WH	101	87-A90-459-010	HLDR,WIRE 2.5-5P	AB.....
PR	5	87-026-681-080	PROTECTOR,5A 60V 491	..C.....
PR	4	87-026-681-080	PROTECTOR,5A 60V 491	..C.....
R	1	87-A00-261-080	RES,M/F 0.56-1W J	..C.....
R	2	87-A00-261-080	RES,M/F 0.56-1W J	..C.....
WH	101	87-A90-460-010	HLDR,WIRE 2.5-7P	..C.....
C	108	87-010-381-080	CAP, ELECT 330-16V	AB.....
C	107	87-010-384-080	CAP, ELECT 100-25V	AB.....
C	106	87-010-408-080	CAP, ELECT 47-50V	AB.....
C	109	87-010-917-090	CAP,E 3300-50 M SMG	.....
C	103	87-016-051-090	CAP,E 2200-35 SMG	AB.....
C	101	87-016-495-090	CAP,E 3300-25 SMG	.....
C	105	87-018-127-080	CAP, CER 470P-50V	AB.....
C	104	87-A10-011-090	CAP,E 2200-25 SMG	.....
C	101	87-A10-520-090	CAP,E 3300-35 M SMG	AB.....
C	102	87-A10-627-090	CAP,E 2200-50 M SMG	.....
C	111	87-010-247-080	CAP, ELECT 100-50V	.....
C	112	87-010-263-080	CAP, ELECT 100-10V	AB.....
C	110	87-010-263-080	CAP, ELECT 100-10V	.B.....
C	114	87-010-374-080	CAP, ELECT 47-10V	AB.....
C	113	87-010-403-080	CAP, ELECT 3.3-50V	AB.....
C	111	87-010-430-080	CAP, ELECT 100-63	AB.....
C	115	87-A11-007-080	CAP,M 0.047-50 J DE	AB.....
C	116	87-A11-007-080	CAP,M 0.047-50 J DE	AB.....

All manuals and user guides at all-guides.com

ELECTRICAL MAIN PARTS LIST - 3/8

C	122	87-010-384-080	CAP, ELECT 100-25V	.....
C	123	87-010-384-080	CAP, ELECT 100-25V	.....
C	123	87-010-408-080	CAP, ELECT 47-50V	AB.....
C	122	87-010-408-080	CAP, ELECT 47-50V	AB.....
C	152	87-010-385-080	CAP, ELECT 220-25V	.....
C	152	87-010-394-080	CAP ELECT220-35V	AB.....
C	152	87-010-409-080	CAP,E 220-50 SME	.....
D	108	87-020-465-080	DIODE,1SS133 (110MA)	AB.....
D	109	87-020-465-080	DIODE,1SS133 (110MA)	AB.....
D	107	87-A40-336-080	ZENER,MTZJ27D T-72	AB.....
D	113	87-020-465-080	DIODE,1SS133 (110MA)	AB.....
D	116	87-070-274-080	DIODE,1N4003 SEM	AB.....
D	117	87-070-274-080	DIODE,1N4003 SEM	AB.....
D	110	87-A40-345-080	ZENER,MTZJ10C	AB.....
D	121	87-A40-455-080	DIODE,RL203 GW	AB.....
D	123	87-A40-455-080	DIODE,RL203 GW	AB.....
D	124	87-A40-455-080	DIODE,RL203 GW	AB.....
D	122	87-A40-455-080	DIODE,RL203 GW	AB.....
D	121	87-A40-535-080	DIODE,1N5393-GOODARK	.....
D	122	87-A40-535-080	DIODE,1N5393-GOODARK	.....
D	124	87-A40-535-080	DIODE,1N5393-GOODARK	.....
D	123	87-A40-535-080	DIODE,1N5393-GOODARK	.....
Q	105	87-026-609-080	TR,KTA1266GR	AB.....
Q	108	87-026-609-080	TR,KTA1266GR	AB.....
Q	102	87-026-610-080	TR,KTC3198GR	AB.....
Q	103	87-026-610-080	TR,KTC3198GR	AB.....
Q	109	87-026-610-080	TR,KTC3198GR	AB.....
Q	106	87-026-610-080	TR,KTC3198GR	AB.....
Q	107	87-026-610-080	TR,KTC3198GR	AB.....
Q	104	87-A30-196-080	TR,2SC4115SRS	AB.....
Q	115	87-026-219-080	TR,DTA144ES (0.3W)	AB.....
Q	112	87-026-269-080	TR,DTA114ES	AB.....
Q	110	87-026-609-080	TR,KTA1266GR	AB.....
Q	113	87-026-609-080	TR,KTA1266GR	.B.....
Q	111	89-213-702-010	TR,2SB1370 (1.8W)	AB.....
R	124	87-A00-261-080	RES,M/F 0.56-1W J	.B.....
RY	101	87-A90-464-010	RELAY, DG12D2-O(M)	AB.....
W	101	83-NE2-618-110	F-CABEL,5P-2.5	AB.....
WH	102	87-A90-459-010	HLDR,WIRE 2.5-5P	AB.....
C	108	87-010-381-080	CAP, ELECT 330-16V	..C.....
C	109	87-010-384-080	CAP, ELECT 100-25V	..C.....
C	107	87-010-384-080	CAP, ELECT 100-25V	..C.....
C	102	87-010-385-080	CAP, ELECT 220-25V	..C.....
C	106	87-010-408-080	CAP, ELECT 47-50V	..C.....
C	103	87-010-917-090	CAP,E 3300-50 M SMG	..C.....
C	101	87-016-495-090	CAP,E 3300-25 SMG	..C.....
C	105	87-018-127-080	CAP, CER 470P-50V	..C.....
C	104	87-A10-627-090	CAP,E 2200-50 M SMG	..C.....
C	111	87-010-247-080	CAP, ELECT 100-50V	..C.....
C	112	87-010-263-080	CAP, ELECT 100-10V	..C.....
C	114	87-010-374-080	CAP, ELECT 47-10V	..C.....
C	110	87-010-384-080	CAP, ELECT 100-25V	..C.....
C	113	87-010-403-080	CAP, ELECT 3.3-50V	..C.....
C	122	87-010-384-080	CAP, ELECT 100-25V	..C.....
C	123	87-010-384-080	CAP, ELECT 100-25V	..C.....
C	130	87-018-131-080	CAP, CER 1000P-50V	..C.....
D	108	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	109	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	101	87-070-274-080	DIODE,1N4003 SEM	..C.....
D	104	87-070-274-080	DIODE,1N4003 SEM	..C.....
D	102	87-070-274-080	DIODE,1N4003 SEM	..C.....
D	103	87-070-274-080	DIODE,1N4003 SEM	..C.....
D	106	87-070-274-080	DIODE,1N4003 SEM	..C.....
D	105	87-070-274-080	DIODE,1N4003 SEM	..C.....
D	107	87-A40-336-080	ZENER,MTZJ27D T-72	..C.....
D	112	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	111	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	117	87-070-274-080	DIODE,1N4003 SEM	..C.....
D	116	87-070-274-080	DIODE,1N4003 SEM	..C.....
D	115	87-A40-116-060	DIODE,RS403L-B-D-51	..C.....
D	110	87-A40-345-080	ZENER,MTZJ10C	..C.....
Q	105	87-026-609-080	TR,KTA1266GR	..C.....
Q	102	87-026-610-080	TR,KTC3198GR	..C.....
Q	104	87-A30-196-080	TR,2SC4115SRS	..C.....
Q	108	87-A30-197-080	TR,KTA1267GR	..C.....
Q	109	87-A30-198-080	TR,KTC3199GR	..C.....
Q	106	87-A30-198-080	TR,KTC3199GR	..C.....
Q	107	87-A30-198-080	TR,KTC3199GR	..C.....
Q	103	87-A30-198-080	TR,KTC3199GR	..C.....
Q	115	87-026-219-080	TR,DTA144ES (0.3W)	..C.....
Q	110	87-A30-197-080	TR,KTA1267GR	..C.....
Q	111	89-213-702-010	TR,2SB1370 (1.8W)	..C.....
RY	1	87-A90-464-010	RELAY, DG12D2-O(M)	..C.....
W	101	85-NF5-628-010	F-CABLE 7P-2.5	..C.....
WH	102	87-A90-460-010	HLDR,WIRE 2.5-7P	..C.....
		87-067-703-010	TAPPING SCREW, BVT2+3-10	AB.....
C	208	87-010-546-080	CAP, ELECT 0.33-50V	AB.....
C	207	87-010-546-080	CAP, ELECT 0.33-50V	AB.....
C	209	87-A11-154-080	CAP,TC U 4700P-16 Z F	AB.....
C	214	87-010-260-080	CAP, ELECT 47-25V	AB.....
C	213	87-010-260-080	CAP, ELECT 47-25V	AB.....
C	212	87-010-403-080	CAP, ELECT 3.3-50V	AB.....

All manuals and user guides at all-guides.com

ELECTRICAL MAIN PARTS LIST - 4/8

C	211	87-010-403-080	CAP, ELECT 3.3-50V	AB
C	219	87-010-544-080	CAP, ELECT 0.1-50V	AB
C	217	87-A11-008-080	CAP,M 0.056-50 J DE	AB
C	218	87-A11-008-080	CAP,M 0.056-50 J DE	AB
C	210	87-A11-154-080	CAP,TC U 4700P-16 Z F	AB
C	220	87-010-544-080	CAP, ELECT 0.1-50V	AB
C	229	87-018-123-080	CAP, CER 220P-50V	AB
C	222	87-018-211-080	CAP, CER 0.01-50	
C	221	87-018-211-080	CAP, CER 0.01-50	
C	223	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	224	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	230	87-018-123-080	CAP, CER 220P-50V	AB
C	235	87-A11-148-080	CAP,TC U 0.1-50 Z F	AB
C	236	87-A11-148-080	CAP,TC U 0.1-50 Z F	AB
C	237	87-A11-155-080	CAP,TC U 0.01-16 Z F	AB
C	256	87-018-115-080	CAP, CER 47P-50V	
C	255	87-018-115-080	CAP, CER 47P-50V	
C	257	87-018-119-080	CAP, CER 100P-50V	
C	258	87-018-119-080	CAP, CER 100P-50V	
C	253	87-018-131-080	CAP, CER 1000P-50V	
C	254	87-018-131-080	CAP, CER 1000P-50V	
D	202	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	205	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	206	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	203	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	201	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	204	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	209	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	217	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	218	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	210	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	216	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	219	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	220	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	221	87-020-465-080	DIODE,1SS133 (110MA)	AB
D	222	87-020-465-080	DIODE,1SS133 (110MA)	AB
J	202	87-A60-238-010	TERMINAL,SP 4P (MSC)	AB
J	203	87-A60-425-010	JACK,PIN 2P YKC21-3838	.B
J	201	87-A60-602-010	JACK,DIA6.3 BLK ST W/SW TC	AB
L	202	87-003-383-010	COIL,1UH-S	AB
L	201	87-003-383-010	COIL,1UH-S	AB
Q	203	87-026-609-080	TR,KTA1266GR	AB
Q	202	87-026-609-080	TR,KTA1266GR	AB
Q	201	87-026-609-080	TR,KTA1266GR	AB
Q	204	87-026-609-080	TR,KTA1266GR	AB
Q	209	87-026-610-080	TR,KTC3198GR	AB
Q	205	87-026-610-080	TR,KTC3198GR	AB
Q	206	87-026-610-080	TR,KTC3198GR	AB
Q	208	87-026-610-080	TR,KTC3198GR	AB
Q	207	87-026-610-080	TR,KTC3198GR	AB
Q	218	87-026-609-080	TR,KTA1266GR	AB
Q	216	87-026-610-080	TR,KTC3198GR	
Q	210	87-026-610-080	TR,KTC3198GR	AB
Q	215	87-026-610-080	TR,KTC3198GR	
Q	215	87-A30-190-080	TR,CC5551	AB
Q	216	87-A30-190-080	TR,CC5551	AB
Q	213	87-A30-214-010	TR,2SB1344	
Q	214	87-A30-214-010	TR,2SB1344	
Q	211	87-A30-215-010	TR,2SD2025	
Q	212	87-A30-215-010	TR,2SD2025	
Q	213	87-A30-255-010	TR,2SB1342	A
Q	214	87-A30-255-010	TR,2SB1342	A
Q	212	87-A30-256-010	TR,2SD1933	A
Q	211	87-A30-256-010	TR,2SD1933	A
Q	232	87-A30-137-010	TR,2SD2494	.B
Q	231	87-A30-137-010	TR,2SD2494	.B
Q	234	87-A30-138-010	TR,2SB1625	.B
Q	233	87-A30-138-010	TR,2SB1625	.B
R	224	87-A00-258-080	RES,M/F 0.22-1W J	AB
R	223	87-A00-258-080	RES,M/F 0.22-1W J	AB
R	249	87-A00-258-080	RES,M/F 0.22-1W J	AB
R	250	87-A00-258-080	RES,M/F 0.22-1W J	AB
		87-067-703-010	TAPPING SCREW, BVT2+3-10	..C
C	207	87-010-546-080	CAP, ELECT 0.33-50V	..C
C	208	87-010-546-080	CAP, ELECT 0.33-50V	..C
C	209	87-A11-154-080	CAP,TC U 4700P-16 Z F	..C
C	211	87-010-403-080	CAP, ELECT 3.3-50V	..C
C	212	87-010-403-080	CAP, ELECT 3.3-50V	..C
C	219	87-010-544-080	CAP, ELECT 0.1-50V	..C
C	213	87-A10-899-080	CAP,E 47-25 M BP SME	..C
C	214	87-A10-899-080	CAP,E 47-25 M BP SME	..C
C	210	87-A11-154-080	CAP,TC U 4700P-16 Z F	..C
C	220	87-010-544-080	CAP, ELECT 0.1-50V	..C
C	229	87-018-123-080	CAP, CER 220P-50V	..C
C	230	87-018-123-080	CAP, CER 220P-50V	..C
C	236	87-A11-148-080	CAP,TC U 0.1-50 Z F	..C
C	235	87-A11-148-080	CAP,TC U 0.1-50 Z F	..C
C	237	87-A11-155-080	CAP,TC U 0.01-16 Z F	..C
D	205	87-020-465-080	DIODE,1SS133 (110MA)	..C
D	201	87-020-465-080	DIODE,1SS133 (110MA)	..C
D	206	87-020-465-080	DIODE,1SS133 (110MA)	..C
D	203	87-020-465-080	DIODE,1SS133 (110MA)	..C

All manuals and user guides at all-guides.com

ELECTRICAL MAIN PARTS LIST - 5/8

D	202	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	204	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	209	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	217	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	218	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	210	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	216	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	219	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	221	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	220	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
D	222	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
J	202	87-033-240-010	TERMINAL,SP 4P32SV1-05	..C.....
J	201	87-A60-602-010	JACK,DIA6.3 BLK ST W/SW TC	..C.....
L	202	87-003-383-010	COIL,1UH-S	..C.....
L	201	87-003-383-010	COIL,1UH-S	..C.....
Q	209	87-A30-190-080	TR,CC5551	..C.....
Q	202	87-A30-197-080	TR,KTA1267GR	..C.....
Q	203	87-A30-197-080	TR,KTA1267GR	..C.....
Q	204	87-A30-197-080	TR,KTA1267GR	..C.....
Q	201	87-A30-197-080	TR,KTA1267GR	..C.....
Q	207	87-A30-198-080	TR,KTC3199GR	..C.....
Q	206	87-A30-198-080	TR,KTC3199GR	..C.....
Q	208	87-A30-198-080	TR,KTC3199GR	..C.....
Q	205	87-A30-198-080	TR,KTC3199GR	..C.....
Q	210	87-A30-190-080	TR,CC5551	..C.....
Q	216	87-A30-190-080	TR,CC5551	..C.....
Q	215	87-A30-190-080	TR,CC5551	..C.....
Q	218	87-A30-197-080	TR,KTA1267GR	..C.....
Q	214	87-A30-214-010	TR,2SB1344	..C.....
Q	213	87-A30-214-010	TR,2SB1344	..C.....
Q	211	87-A30-215-010	TR,2SD2025	..C.....
Q	212	87-A30-215-010	TR,2SD2025	..C.....
R	223	87-A00-258-080	RES,M/F 0.22-1W J	..C.....
R	224	87-A00-258-080	RES,M/F 0.22-1W J	..C.....
R	249	87-A00-258-080	RES,M/F 0.22-1W J	..C.....
R	250	87-A00-258-080	RES,M/F 0.22-1W J	..C.....
C	308	87-010-263-080	CAP, ELECT 100-10V	AB.....
C	307	87-010-263-080	CAP, ELECT 100-10V	AB.....
C	309	87-018-115-080	CAP, CER 47P-50V	.....
C	302	87-018-131-080	CAP, CER 1000P-50V	AB.....
C	301	87-018-131-080	CAP, CER 1000P-50V	AB.....
C	304	87-018-131-080	CAP, CER 1000P-50V	AB.....
C	303	87-018-131-080	CAP, CER 1000P-50V	AB.....
C	315	87-010-374-080	CAP, ELECT 47-10V	AB.....
C	318	87-010-546-080	CAP, ELECT 0.33-50V	AB.....
C	317	87-010-546-080	CAP, ELECT 0.33-50V	AB.....
C	310	87-018-115-080	CAP, CER 47P-50V	.....
C	311	87-A11-009-080	CAP,M 0.068-50 J DE	AB.....
C	312	87-A11-009-080	CAP,M 0.068-50 J DE	AB.....
C	326	87-018-205-080	CAP, CERA-SOL 0.022	AB.....
C	361	87-010-374-080	CAP, ELECT 47-10V	AB.....
C	360	87-010-401-080	CAP, ELECT 1-50V	AB.....
C	399	87-018-127-080	CAP, CER 470P-50V	AB.....
C	401	87-010-544-080	CAP, ELECT 0.1-50V	AB.....
C	402	87-010-544-080	CAP, ELECT 0.1-50V	AB.....
C	403	87-018-118-080	CAP,TC-U 82P-50 B	AB.....
C	404	87-018-118-080	CAP,TC-U 82P-50 B	AB.....
C	412	87-010-405-080	CAP, ELECT 10-50V	AB.....
C	411	87-010-405-080	CAP, ELECT 10-50V	AB.....
C	452	87-010-382-080	CAP, ELECT 22-25V	AB.....
C	459	87-018-128-080	CAP, CERA-SOL SS 560P	AB.....
C	458	87-018-131-080	CAP, CER 1000P-50V	AB.....
C	457	87-A10-772-080	CAP,M 5600P-50 J	AB.....
C	461	87-018-126-080	CAP,TC-U 390P-50 B	AB.....
C	462	87-018-126-080	CAP,TC-U 390P-50 B	AB.....
CN	301	87-A60-620-010	CONN,3P V 2MM JMT	AB.....
CN	351	87-A60-625-010	CONN,8P V 2MM JMT	AB.....
D	401	87-020-465-080	DIODE,1SS133 (110MA)	AB.....
IC	301	87-017-889-010	IC,NJM4558LD	AB.....
IC	401	87-017-889-010	IC,NJM4558LD	AB.....
L	451	87-007-342-010	COIL,OSC 85K BIAS	AB.....
Q	306	87-026-218-080	TR,DTC144ES (0.2W)	AB.....
Q	309	87-026-609-080	TR,KTA1266GR	AB.....
Q	303	87-A30-090-080	FET,2SK2541	AB.....
Q	304	87-A30-090-080	FET,2SK2541	AB.....
Q	301	87-A30-091-080	FET,2SJ460	AB.....
Q	302	87-A30-091-080	FET,2SJ460	AB.....
Q	305	87-A30-091-080	FET,2SJ460	AB.....
Q	308	87-A30-091-080	FET,2SJ460	AB.....
Q	307	87-A30-091-080	FET,2SJ460	AB.....
Q	310	87-026-609-080	TR,KTA1266GR	AB.....
Q	444	87-026-609-080	TR,KTA1266GR	AB.....
Q	443	87-026-609-080	TR,KTA1266GR	AB.....
Q	454	87-026-610-080	TR,KTC3198GR	AB.....
Q	455	87-026-610-080	TR,KTC3198GR	.....
Q	451	87-026-610-080	TR,KTC3198GR	AB.....
Q	453	87-026-610-080	TR,KTC3198GR	AB.....
SFR	451	87-024-355-080	SFR,33K DIA6 H	AB.....
SFR	452	87-024-355-080	SFR,33K DIA6 H	AB.....
C	307	87-010-263-080	CAP, ELECT 100-10V	..C.....
C	308	87-010-263-080	CAP, ELECT 100-10V	..C.....
C	304	87-018-131-080	CAP, CER 1000P-50V	..C.....

All manuals and user guides at all-guides.com

ELECTRICAL MAIN PARTS LIST - 6/8

C	303	87-018-131-080	CAP, CER 1000P-50V	..C.....
C	302	87-018-131-080	CAP, CER 1000P-50V	..C.....
C	301	87-018-131-080	CAP, CER 1000P-50V	..C.....
C	315	87-010-374-080	CAP, ELECT 47-10V	..C.....
C	317	87-010-546-080	CAP, ELECT 0.33-50V	..C.....
C	318	87-010-546-080	CAP, ELECT 0.33-50V	..C.....
C	361	87-010-374-080	CAP, ELECT 47-10V	..C.....
C	360	87-010-401-080	CAP, ELECT 1-50V	..C.....
C	399	87-018-127-080	CAP, CER 470P-50V	..C.....
C	401	87-010-544-080	CAP, ELECT 0.1-50V	..C.....
C	402	87-010-544-080	CAP, ELECT 0.1-50V	..C.....
C	403	87-018-118-080	CAP,TC-U 82P-50 B	..C.....
C	404	87-018-118-080	CAP,TC-U 82P-50 B	..C.....
C	412	87-010-405-080	CAP, ELECT 10-50V	..C.....
C	411	87-010-405-080	CAP, ELECT 10-50V	..C.....
C	452	87-010-382-080	CAP, ELECT 22-25V	..C.....
C	459	87-018-128-080	CAP, CERA-SOL SS 560P	..C.....
C	458	87-018-131-080	CAP, CER 1000P-50V	..C.....
C	462	87-018-126-080	CAP,TC-U 390P-50 B	..C.....
C	461	87-018-126-080	CAP,TC-U 390P-50 B	..C.....
CON	301	87-099-827-010	CONN,3P S2M-3W	..C.....
CON	351	87-099-832-010	CONN,8P S2M-8W	..C.....
D	401	87-020-465-080	DIODE,1SS133 (110MA)	..C.....
IC	301	87-017-889-010	IC,NJM4558LD	..C.....
IC	401	87-017-889-010	IC,NJM4558LD	..C.....
L	451	87-007-342-010	COIL,OSC 85K BIAS	..C.....
Q	306	87-026-218-080	TR,DTC144ES (0.2W)	..C.....
Q	304	87-A30-090-080	FET,2SK2541	..C.....
Q	303	87-A30-090-080	FET,2SK2541	..C.....
Q	305	87-A30-091-080	FET,2SJ460	..C.....
Q	307	87-A30-091-080	FET,2SJ460	..C.....
Q	301	87-A30-091-080	FET,2SJ460	..C.....
Q	302	87-A30-091-080	FET,2SJ460	..C.....
Q	308	87-A30-091-080	FET,2SJ460	..C.....
Q	309	87-A30-197-080	TR,KTA1267GR	..C.....
Q	310	87-A30-197-080	TR,KTA1267GR	..C.....
Q	442	87-A30-197-080	TR,KTA1267GR	..C.....
Q	443	87-A30-197-080	TR,KTA1267GR	..C.....
Q	453	87-026-610-080	TR,KTC3198GR	..C.....
Q	451	87-026-610-080	TR,KTC3198GR	..C.....
Q	454	87-026-610-080	TR,KTC3198GR	..C.....
SFR	452	87-A90-432-080	SFR,30K H NVZ6TLTA	..C.....
SFR	451	87-A90-432-080	SFR,30K H NVZ6TLTA	..C.....
C	601	87-018-195-080	CAP, CER 1200P-16V	AB.....
C	602	87-018-195-080	CAP, CER 1200P-16V	AB.....
C	617	87-010-260-080	CAP, ELECT 47-25V	AB.....
C	616	87-010-260-080	CAP, ELECT 47-25V	AB.....
C	611	87-010-545-080	CAP, ELECT 0.22-50V	AB.....
C	613	87-010-545-080	CAP, ELECT 0.22-50V	AB.....
C	614	87-010-545-080	CAP, ELECT 0.22-50V	AB.....
C	612	87-010-545-080	CAP, ELECT 0.22-50V	AB.....
C	615	87-018-104-080	CAP,TC-U 10P-50 SL	AB.....
CN	602	87-099-194-010	CONN,6P 6216V	AB.....
CN	601	87-099-719-010	CONN,30P TYK-B(X)	AB.....
D	601	87-A40-466-080	ZENER,MTZJ2.7A	AB.....
D	602	87-A40-466-080	ZENER,MTZJ2.7A	AB.....
FB	601	87-008-372-080	FILTER, EMI BL OIRNI	.....
IC	601	87-A20-715-010	IC,M62439SP	AB.....
J	601	87-A60-425-010	JACK,PIN 2P YKC21-3838	AB.....
C	601	87-018-195-080	CAP, CER 1200P-16V	..C.....
C	602	87-018-195-080	CAP, CER 1200P-16V	..C.....
C	617	87-010-408-080	CAP, ELECT 47-50V	..C.....
C	616	87-010-408-080	CAP, ELECT 47-50V	..C.....
C	612	87-010-545-080	CAP, ELECT 0.22-50V	..C.....
C	611	87-010-545-080	CAP, ELECT 0.22-50V	..C.....
C	613	87-010-545-080	CAP, ELECT 0.22-50V	..C.....
C	614	87-010-545-080	CAP, ELECT 0.22-50V	..C.....
C	615	87-018-104-080	CAP,TC-U 10P-50 SL	..C.....
CON	602	87-099-194-010	CONN,6P 6216V	..C.....
CON	601	87-099-719-010	CONN,30P TYK-B(X)	..C.....
D	601	87-A40-466-080	ZENER,MTZJ2.7A	..C.....
D	602	87-A40-466-080	ZENER,MTZJ2.7A	..C.....
IC	601	87-A20-715-010	IC,M62439SP	..C.....
J	601	87-A60-425-010	JACK,PIN 2P YKC21-3838	..C.....
C	707	87-010-112-080	CAP, ELECT 100-16V	AB.....
C	709	87-010-248-080	CAP, ELECT 220-10V	AB.....
C	701	87-010-404-080	CAP, ELECT 4.7-50V	AB.....
C	706	87-018-131-080	CAP, CER 1000P-50V	AB.....
C	704	87-018-131-080	CAP, CER 1000P-50V	AB.....
C	705	87-018-131-080	CAP, CER 1000P-50V	AB.....
C	708	87-A11-144-080	CAP,TC U 0.1-50 K B	AB.....
C	702	87-A11-155-080	CAP,TC U 0.01-16 Z F	AB.....
C	703	87-A11-155-080	CAP,TC U 0.01-16 Z F	AB.....
C	710	87-010-112-080	CAP, ELECT 100-16V	AB.....
C	714	87-010-112-080	CAP, ELECT 100-16V	AB.....
C	715	87-018-119-080	CAP, CER 100P-50V	AB.....
C	713	87-018-149-080	CAP,TC-U 15P-50 CH	AB.....
C	712	87-018-149-080	CAP,TC-U 15P-50 CH	AB.....
D	701	87-017-931-080	ZENER,MTZJ5.6B	AB.....
D	702	87-020-465-080	DIODE,1SS133 (110MA)	.....
IC	701	87-070-127-110	IC,LC72131 D	AB.....
L	701	87-005-847-080	COIL,2.2UH(CECS)	AB.....

All manuals and user guides at all-guides.com

ELECTRICAL MAIN PARTS LIST - 7/8

Q	701	87-A30-196-080	TR,2SC4115SRS	AB
X	701	87-A70-061-010	VIB,XTAL 4.500MHZ CSA-309	AB
C	707	87-010-112-080	CAP, ELECT 100-16V	..C
C	709	87-010-248-080	CAP, ELECT 220-10V	..C
C	701	87-010-404-080	CAP, ELECT 4.7-50V	..C
C	704	87-018-131-080	CAP, CER 1000P-50V	..C
C	705	87-018-131-080	CAP, CER 1000P-50V	..C
C	706	87-018-131-080	CAP, CER 1000P-50V	..C
C	702	87-A11-155-080	CAP,TC U 0.01-16 Z F	..C
C	703	87-A11-155-080	CAP,TC U 0.01-16 Z F	..C
C	714	87-010-112-080	CAP, ELECT 100-16V	..C
C	710	87-010-112-080	CAP, ELECT 100-16V	..C
C	715	87-018-119-080	CAP, CER 100P-50V	..C
C	713	87-018-149-080	CAP,TC-U 15P-50 CH	..C
C	712	87-018-149-080	CAP,TC-U 15P-50 CH	..C
D	701	87-A40-234-080	ZENER,MTZJ5.6A	..C
IC	701	87-070-127-110	IC,LC72131 D	..C
L	701	87-005-847-080	COIL,2.2UH(CECS)	..C
Q	701	87-A30-196-080	TR,2SC4115SRS	..C
X	701	87-A70-061-010	VIB,XTAL 4.500MHZ CSA-309	..C
C	746	87-A11-155-080	CAP,TC U 0.01-16 Z F	AB
C	758	87-010-112-080	CAP, ELECT 100-16V	AB
C	753	87-010-408-080	CAP, ELECT 47-50V	AB
C	752	87-018-143-080	CAP,TC-U 4.7P-50 CH	
C	755	87-A11-144-080	CAP,TC U 0.1-50 K B	AB
C	757	87-A11-155-080	CAP,TC U 0.01-16 Z F	AB
C	759	87-A11-155-080	CAP,TC U 0.01-16 Z F	AB
C	756	87-A11-155-080	CAP,TC U 0.01-16 Z F	AB
C	762	87-010-400-080	CAP, ELECT 0.47-50V	AB
C	763	87-010-401-080	CAP, ELECT 1-50V	AB
C	764	87-010-401-080	CAP, ELECT 1-50V	AB
C	769	87-010-403-080	CAP, ELECT 3.3-50V	AB
C	761	87-010-404-080	CAP, ELECT 4.7-50V	AB
C	766	87-010-407-080	CAP, ELECT 33-50V	AB
C	765	87-018-115-080	CAP, CER 47P-50V	AB
C	768	87-A11-147-080	CAP,TC U 0.047-50 Z F	AB
C	774	87-010-405-080	CAP, ELECT 10-50V	AB
C	771	87-010-406-080	CAP, ELECT 22-50	AB
C	773	87-018-131-080	CAP, CER 1000P-50V	AB
C	773	87-018-195-080	CAP, CER 1200P-16V	
C	773	87-018-196-080	CAP, CER 1500P-16V	
C	776	87-A11-155-080	CAP,TC U 0.01-16 Z F	AB
C	770	87-A11-155-080	CAP,TC U 0.01-16 Z F	AB
C	789	87-010-403-080	CAP, ELECT 3.3-50V	AB
C	786	87-010-405-080	CAP, ELECT 10-50V	AB
C	785	87-010-405-080	CAP, ELECT 10-50V	AB
C	787	87-018-196-080	CAP, CER 1500P-16V	
C	788	87-018-196-080	CAP, CER 1500P-16V	
C	784	87-018-199-080	CAP, CER 3300P	AB
C	783	87-018-199-080	CAP, CER 3300P	AB
C	784	87-018-202-080	CAP.CERAM.6800PF	
C	783	87-018-202-080	CAP.CERAM.6800PF	
C	788	87-A11-153-080	CAP,TC U 2200P-16 Z F	AB
C	787	87-A11-153-080	CAP,TC U 2200P-16 Z F	AB
C	790	87-010-403-080	CAP, ELECT 3.3-50V	AB
D	752	87-020-465-080	DIODE,1SS133 (110MA)	
D	751	87-020-465-080	DIODE,1SS133 (110MA)	AB
IC	751	87-A20-913-010	IC,LA1837NL	AB
L	771	87-A50-266-010	COIL,FM DET-2N(TOK)	AB
L	772	87-A90-052-010	FLTR,CFMT-450A(TOK)	
L	772	87-A90-733-010	FLTR,PCFAZH-450 (TOK)	AB
X	751	87-030-354-010	VIB,CF BFU 450C	
C	746	87-A11-155-080	CAP,TC U 0.01-16 Z F	..C
C	758	87-010-112-080	CAP, ELECT 100-16V	..C
C	753	87-010-408-080	CAP, ELECT 47-50V	..C
C	756	87-A11-155-080	CAP,TC U 0.01-16 Z F	..C
C	759	87-A11-155-080	CAP,TC U 0.01-16 Z F	..C
C	757	87-A11-155-080	CAP,TC U 0.01-16 Z F	..C
C	762	87-010-400-080	CAP, ELECT 0.47-50V	..C
C	763	87-010-401-080	CAP, ELECT 1-50V	..C
C	764	87-010-401-080	CAP, ELECT 1-50V	..C
C	769	87-010-403-080	CAP, ELECT 3.3-50V	..C
C	761	87-010-404-080	CAP, ELECT 4.7-50V	..C
C	766	87-010-407-080	CAP, ELECT 33-50V	..C
C	765	87-018-115-080	CAP, CER 47P-50V	..C
C	768	87-A11-147-080	CAP,TC U 0.047-50 Z F	..C
C	774	87-010-405-080	CAP, ELECT 10-50V	..C
C	771	87-010-406-080	CAP, ELECT 22-50	..C
C	773	87-018-131-080	CAP, CER 1000P-50V	..C
C	770	87-A11-155-080	CAP,TC U 0.01-16 Z F	..C
C	789	87-010-403-080	CAP, ELECT 3.3-50V	..C
C	786	87-010-405-080	CAP, ELECT 10-50V	..C
C	785	87-010-405-080	CAP, ELECT 10-50V	..C
C	783	87-018-199-080	CAP, CER 3300P	..C
C	784	87-018-199-080	CAP, CER 3300P	..C
C	787	87-A11-153-080	CAP,TC U 2200P-16 Z F	..C
C	788	87-A11-153-080	CAP,TC U 2200P-16 Z F	..C
C	790	87-010-403-080	CAP, ELECT 3.3-50V	..C
D	751	87-020-465-080	DIODE,1SS133 (110MA)	..C
IC	751	87-A20-913-010	IC,LA1837NL	..C
L	771	87-A50-266-010	COIL,FM DET-2N(TOK)	..C
L	772	87-A90-733-010	FLTR,PCFAZH-450 (TOK)	..C

All manuals and user guides at all-guides.com

ELECTRICAL MAIN PARTS LIST - 8/8

C	856	87-010-405-080	CAP, ELECT 10-50V	
C	855	87-010-405-080	CAP, ELECT 10-50V	
C	859	87-018-109-080	CAP, CER 22P-50V	
C	858	87-018-109-080	CAP, CER 22P-50V	
C	851	87-018-123-080	CAP, CER 220P-50V	
C	852	87-018-123-080	CAP, CER 220P-50V	
C	853	87-018-127-080	CAP, CER 470P-50V	
C	854	87-A11-144-080	CAP,TC U 0.1-50 K B	
C	857	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	860	87-A11-155-080	CAP,TC U 0.01-16 Z F	
IC	851	87-A20-502-010	IC,BU1920	
L	851	87-005-847-080	COIL,2.2UH(CECS)	
Q	851	87-026-610-080	TR,KTC3198GR	
X	851	87-A70-091-010	VIB,XTAL 4.332MHZ CSA-309	
C	805	87-A11-144-080	CAP,TC U 0.1-50 K B	AB
C	807	87-A11-144-080	CAP,TC U 0.1-50 K B	AB
C	808	87-A11-155-080	CAP,TC U 0.01-16 Z F	AB
C	809	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	802	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	803	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	801	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	804	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	812	87-010-408-080	CAP, ELECT 47-50V	
C	813	87-018-131-080	CAP, CER 1000P-50V	AB
C	810	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	811	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	901	87-A11-148-080	CAP,TC U 0.1-50 Z F	AB
C	924	87-014-049-080	CAP,PP 470P-100 J	
C	922	87-018-099-080	CAP CERA 3.9P-50	
C	923	87-018-102-080	CAP,TC-U 6.8P-50 SL	
C	921	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	931	87-010-263-080	CAP, ELECT 100-10V	
C	932	87-010-400-080	CAP, ELECT 0.47-50V	
C	939	87-014-073-080	CAP,PP 4700P-100 J	
C	938	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	935	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	936	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	934	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	937	87-A11-155-080	CAP,TC U 0.01-16 Z F	
C	940	87-014-051-080	CAPACITOR (PP), 560P	
C	944	87-018-104-080	CAP,TC-U 10P-50 SL	AB
C	941	87-018-109-080	CAP, CER 22P-50V	
C	943	87-A11-144-080	CAP,TC U 0.1-50 K B	AB
CF	802	82-785-747-010	CF MS2 GHY R	
CF	801	87-008-261-010	FILTER, SFE10.7MA5-A	AB
CF	801	87-008-423-010	CERAMIC FILTER, SFE10.7	
D	923	87-020-465-080	DIODE,1SS133 (110MA)	
D	921	87-020-465-080	DIODE,1SS133 (110MA)	
D	922	87-020-465-080	DIODE,1SS133 (110MA)	
D	941	87-020-465-080	DIODE,1SS133 (110MA)	
FFE	801	A8-6ZA-19C-170	6ZA-1 YFEENC	
FFE	801	A8-8ZA-190-030	8ZA-1 FEUNM	AB
FFE	801	A8-8ZA-191-030	8ZA-1 YFEUNM	
J	801	87-A60-202-010	TERMINAL,ANT 4P MSP-154V-02	AB
J	802	87-A60-403-010	TERMINAL,ANT PAL 2P HSP-312V05	
J	931	81-754-629-010	CONNECTOR, 2P	
L	801	87-005-847-080	COIL,2.2UH(CECS)	AB
L	934	87-005-372-080	COIL S 1MHM	
L	933	87-A50-159-010	COIL,10MH K C2B	
L	942	87-A50-019-010	COIL,OSC LW(COI)	
L	941	87-A50-020-010	COIL,ANT LW(COI)	
L	941	87-A50-022-010	COIL,ANT SW(COI)	
L	942	87-A50-173-010	COIL,OSC SW-N(COI)	
L	981	87-NF4-650-010	COIL,AM PACK 4N(TOK)	AB
L	981	87-NF4-651-110	COIL,AM PACK2N(TOM)	
L	981	88-NF8-625-010	COIL,AM PACK3N(TOK)	
Q	801	87-026-214-080	TR,DTA114YS (0.3W)	AB
Q	802	87-026-214-080	TR,DTA114YS (0.3W)	
Q	803	89-305-352-380	TR,2SC535(B/C)	
Q	941	87-026-269-080	TR,DTA114ES	
Q	940	87-026-269-080	TR,DTA114ES	
Q	942	87-A30-164-080	TR,CSC2001K	
TC	941	87-011-220-080	TRIMMER CAP 20P VTC	
TC	943	87-011-221-080	CAP, TRIMMER 30P	
TC	942	87-011-221-080	CAP, TRIMMER 30P	
C	808	87-A11-155-080	CAP,TC U 0.01-16 Z F	..C
C	804	87-A11-155-080	CAP,TC U 0.01-16 Z F	..C
C	803	87-A11-155-080	CAP,TC U 0.01-16 Z F	..C
C	813	87-018-131-080	CAP, CER 1000P-50V	..C
C	944	87-018-147-080	CAP,TC-U 10P-50 CH	..C
CF	801	87-008-261-010	FILTER, SFE10.7MA5-A	..C
FFE	801	A8-8ZA-190-030	8ZA-1 FEUNM	..C
J	801	87-A60-202-010	TERMINAL,ANT 4P MSP-154V-02	..C
L	801	87-005-847-080	COIL,2.2UH(CECS)	..C
L	981	87-NF4-650-010	COIL,AM PACK 4N(TOK)	..C
Q	801	87-026-214-080	TR,DTA114YS (0.3W)	..C
FC	101	87-033-147-010	FUSE CLAMP	A.C
FC	102	87-033-147-010	FUSE CLAMP	A.C
SW	101	87-A90-165-010	SW,SL 1-2-3 SWS2301	A.C
T	101	87-A60-317-010	TERMINAL, 1P MSC	A.C
T	102	87-A60-317-010	TERMINAL, 1P MSC	A.C

All manuals and user guides at all-guides.com

MECHANICAL PARTS LIST - 1/1

NOTE: The characters in the suffix column indicate the part usage.

LH(Lo) .....XX.....A.....
U .....XX.....B.....
LH(Hi) .....XX.....C.....

REF.NO	PARTS NO.	kanri NO.	DESCRIPTION	SUFFIX
	82-NE6-067-010		BADGE,AIWA 30N	ABC
	8Z-NF9-002-010		PANEL,TRAY H	ABC
	8Z-NF9-003-010		BOX,CASS 1 1WAY	ABC
	8Z-NF9-004-010		BOX,CASS 2	ABC
	8Z-NF9-021-010		CABI,REAR USTM	.B
	8Z-NF9-022-010		CABI,REAR LHSTM	A
	8Z-NF9-028-010		CABI,REAR LHSTM S333	..C
	8Z-NF9-029-010		CABI,REAR EZSTE S333	
	8Z-NF9-030-010		CABI,REAR HRJSTM S333	
	8Z-NF9-031-010		CABI,FR U	ABC
	8Z-NF9-032-010		BOX,CASS 1R	
	8Z-NF9-042-010		PANEL,TOP V-2	ABC
	8Z-NF9-043-010		PANEL,RIGHT S V-2	ABC
	8Z-NF9-065-010		CABI,REAR USTN	
	8Z-NF9-066-010		CABI,REAR LHSTN	
	8Z-NF9-067-010		CABI,REAR USTFD	
	8Z-NF9-068-010		CABI,REAR EZSTE S223	
	8Z-NF9-069-010		CABI,REAR EZSTE	
	8Z-NF9-070-010		CABI,REAR KSTE	
	88-NF9-056-010		KNOB,RTRY MIC	
	8Z-NF9-009-010		KNOB,RTRY VOL	ABC
	8Z-NF9-010-010		KNOB,RTRY JOG	ABC
	8Z-NF9-012-010		KEY,FUN	ABC
	8Z-NF9-013-010		KEY,ASSY OPE 1W	ABC
	8Z-NF9-016-010		KEY,CD	ABC
	8Z-NF9-017-010		KEY,GEQ	ABC
	8Z-NF9-033-010		KEY,ASSY OPE R	
	8Z-NF9-034-010		KEY,OPE R	
	8Z-NF9-035-010		REFLECTOR,OPE R	
	86-NFZ-001-010		WINDOW,TOP	ABC
	8Z-NF9-005-010		WINDOW,CD	ABC
	8Z-NF9-006-010		WINDOW,DISP H	A
	8Z-NF9-007-010		WINDOW,CASS 1	ABC
	8Z-NF9-008-010		WINDOW,CASS 2	ABC
	8Z-NF9-039-010		WINDOW,DISP U	.B
	8Z-NF9-062-010		WINDOW,DISP H S333	..C
	84-ZG1-245-210		CAP,OPTICAL	ABC
	82-NF5-218-010		SPR-T,EJECT 1 (SIN)	ABC
	82-NF5-219-010		SPR-T,EJECT 2 (SIN)	ABC
	82-NF5-229-010		PLATE,LOCK	ABC
	86-NF9-224-010		SPR-C,LOCK	ABC
	87-NF4-216-010		HLDR,LOCK 1	ABC
	87-NF4-217-010		HLDR,LOCK 2	ABC
	87-NF4-221-010		HLDR,CABLE	ABC
	87-NF8-220-010		DMPR,150	ABC
	88-NF5-208-010		HLDR,PWB-M N	ABC
	8Z-NB8-240-010		COVER, PL	ABC
	87-067-641-010		UTT2+3-8(W/O SLOT)BL	ABC
	87-067-688-010		BVTT+3-6	ABC
	87-067-703-010		TAPPING SCREW, BVT2+3-10	ABC
	87-067-975-010		S-SCREW,IT+4-8	ABC
	87-721-097-410		QT2+3-12 GLD	ABC
	87-723-096-410		QT2+3-10W/O SLOT BL	ABC
	87-NF4-224-010		S-SCREW,IT3B+3-8 CU	ABC
	87-050-034-010		AC CORD ASSY,E	
	87-050-079-010		AC-CORD ASSY,E	A.C
	87-085-185-010		BUSHING, AC CORD (E)	A.C
	87-085-189-010		BUSHING, CORD (U)	.B
	87-099-811-010		PLUG,ADPTR CONV(K)	
	87-A80-110-010		AC CORD ASSY,U SPT-2W	.B
	88-906-251-110		FF-CABLE,6P 1.25	ABC
	88-911-201-110		FF-CABLE,11P 1.25	ABC
	88-913-221-110		FF-CABLE, 13P 1.25 220MM	ABC
C 814	87-A11-155-080		CAP,TC U 0.01-16 Z F	
F 101	87-035-139-010		FUSE, 2.5A T 250V	..C
F 101	87-035-219-010		FUSE, 500MA'T'	
F 101	87-035-222-010		FUSE, 1AT	
F 101	87-035-224-010		FUSE, 1.6AT	A
F 101	87-035-485-010		FUSE,2A 125V D UL	.B
PT 101	88-NF8-605-010		PT,8NF-8LH	..C
PT 101	88-NF9-608-010		PT,8NF9-EKZ	
PT 101	88-NF9-610-010		PT,8NF-9 HI-HR	
PT 101	88-NF9-611-010		PT,8NF-9 HI-LH	A
PT 101	8Z-NF9-620-010		PT,ZNF-9 U	.B
PT 101	8Z-NF9-622-010		PT,ZNF-9 EZ-HI	
	82-NF7-210-110		GUIDE,FL (*)	ABC
WH 101	87-A90-459-010		HLDR,WIRE 2.5-5P	AB
WH 101	87-A90-460-010		HLDR,WIRE 2.5-7P	..C
W 101	83-NE2-618-110		F-CABEL,5P-2.5	AB
WH 102	87-A90-459-010		HLDR,WIRE 2.5-5P	AB
W 101	85-NF5-628-010		F-CABLE 7P-2.5	..C
WH 102	87-A90-460-010		HLDR,WIRE 2.5-7P	..C
	87-067-703-010		TAPPING SCREW, BVT2+3-10	AB
	87-067-703-010		TAPPING SCREW, BVT2+3-10	..C

All manuals and user guides at all-guides.com

ACCESSORIES / PACKAGE LIST - 1/1

NOTE: The characters in the suffix column indicate the part usage.

REF.NO		PARTS NO.	KANRI NO.	DESCRIPTION	SUFFIX
		8Z-NF9-902-010		IB,LH(ESP)M	A.....
		8Z-NF9-903-010		IB,U(ESF)M	.B.....
		8Z-NF9-905-010		IB,K(E)E	.....
		8Z-NF9-906-010		IB,EZ(9L)E	.....
		8Z-NF9-912-010		IB,LH(ESP)M -333	..C.....
		8Z-NF9-916-010		IB,EZ(9L)E -223	.....
		8Z-NF9-926-010		IB,EZ(9L)E -333	.....
		87-006-268-010		AM-LOOP ANT NC (UN)	.....
		87-043-095-010		WIRE ANTENNA	.....
		87-043-106-010		WIRE, FM ANT (Z)	.....
		87-043-115-010		ANT,FEEDER FM	ABC.....
		87-A91-017-010		PLUG,CONVERSION JT-0476	A.C.....
		8Z-NF8-701-010		RC UNIT,RC-ZAS01	.....
		8Z-NF9-701-010		RC UNIT,ZAS02	ABC.....
ANT	0	87-006-225-010		AM LOOP ANT NC2	ABC.....
ANT	0	87-006-269-010		AM LOOP ANT (UN)	.....

all-guides.com

All manuals and user guides at all-guides.com

SCHEMATIC DIAGRAM – 1 (MAIN : U)



All manuals and user guides at all-guides.com

SCHEMATIC DIAGRAM – 1 (MAIN : 2LH)



All manuals and user guides at all-guides.com

SCHEMATIC DIAGRAM – 1 (MAIN : 3LH)



All manuals and user guides at all-guides.com

SCHEMATIC DIAGRAM – 1 (FRONT : U,2LH,3LH)



All manuals and user guides at all-guides.com

all-guides.com

サービス技術ニュース	
番号	連絡内容
G－　－	
G－　－	
G－　－	

アイワ株式会社
AIWA CO.,LTD.

〒110-8710 東京都台東区池之端1-2-11 ☎03(3827)3111 （代表）

9301896

Tokyo Japan

Printed in Singapore